



SPREADER PARTS FOR ACCUPRO 2000, SR-2000 and SS-2 DROP SPREADER

Product Code	Description	Part # in Manual	AccuPro Key Number	SR-2000 Key Number	SS-2 Key Number
4910351	Hopper Assembly - For AccuPro 2000	791035	1		
4910361	Hopper Assembly - For SR-2000	791036		1	
4901151	Hopper*	790115	2	2	
4800451	Helical Cone Assembly*	780945	3	3	
4920011	Helical Cone Retainer with Bearing Shield	792001	4	4	
4809411	Helical Cone	780941	5	5	
4920021	Shutoff Plate Retainer/Shutoff Plate Base	792002	6	6	
4903411	Pointer* - For AccuPro 2000	790341	7		
4903401	Pointer* - For SR-2000	790340		7	
4903211	Rate Control Housing*	790321	8	8	
4903951	Rate Control Rod Assembly*	790395	9	9	
4920031	Rate Control Knob with Washer*	792003	10	10	
4903301	Rate Control Plate*	790330	11	11	
4902651	Pivot Lever/Main Shutoff Plate Assembly* - For AccuPro 2000	790265	12		
4902661	Pivot Lever/Main Shutoff Plate Assembly* - For SR-2000	790266		12	
4920041	Agitator Bearing, set*	792004	13	13	
4801001	Agitator Pin	780100	14	14	
4801951	Rotor and Gear Carrier Assembly	780195	15	15	
4900201	Rotor Shaft with Roll Pin	790020	16	16	
4801911	Rotor Plate with Roll Pin	780191	17	17	
4801551	Gear Carrier, Complete	780155	18	18	
4801221	Pinion Gear with Roll Pin	780122	19	19	
4801211	Ring Gear with Roll Pin	780121	20	20	
4801101	Gearbox Cover Half (set of 2)	780110	21	21	
4802001	Axle Collar with Set Screw (each)	780200	22	22	
4900151	Axle with roll pin, Complete	790015	23	23	
4901201	Drive Wheel with Pin	790120	24	24	
4901301	Idler Wheel	790130	25	25	
4901511	Axle Bearings (set of 4)	790151	26	26	
4900451	Frame Assembly (includes 26) - For AccuPro 2000	790045	27		
4900461	Frame Assembly (includes 26) - For SR-2000	790046		27	
4900611	Rest - For AccuPro 2000	790061	28		
4900601	Rest - For SR-2000	790060		28	
4900751	Handle Assembly (includes 30, 31) - For AccuPro 2000	790075	29		
4900761	Handle Assembly (includes 30, 31) - For SR-2000	790076		29	
4902151	Main Shutoff Lever	790215	30	30	
4000061	Hand Grips (set of 2)	1000061	31	31	
4902501	Main Shutoff Control Rod	790250	32	32	
4901411	Hopper Screen	790141	33	33	
4804401	Hopper Screen Clip (set of 2)	780440	34	34	
4901611	Hopper Cover	790161	35	35	
4909051	Fastener Package - For AccuPro 2000	790905	36		
4802201	Auxiliary Shutoff Plate - For SR-2000	780220		36	
4905501	Auxiliary Shutoff Cable Bracket - For SR-2000	790550		37	
4904901	Auxiliary Shutoff Control Cable - For SR-2000	790490		38	
4905601	Auxiliary Shutoff Clamp - For SR-2000	790560		39	
4000601	Deflector Shield, Complete	1000060	200	40	
4000591	Deflector Lever Bracket - For SR-2000	1000059		42	
4000531	Deflector Control Rod - For SR-2000	1000053		43	
4000521	Deflector Rod Spring - For SR-2000	1000052		44	
4909701	Calibration Key	791082	37	45	
4144751	Hopper Assembly	14475-1			1
4144791	Shutoff bar Assembly	14479-1			2
4142281	Agitator/Axle Assembly LH&RH	14228-1			3
4142311	Bearing Support Assembly	14231			4
4142351	Agitator Baffle	14235			5
4142271	End Hanger	14227			6
4140071	Axle Grease Seal	14007			7
4142221	Plate Assembly-bearing end	14222-1			8
4900051	Grease Fitting	90005			9
4140061	Axle Bearing	14006			10
4150431	Wheel and Tire Assembly	15043			11
4127141	Leg (pair)	12714			12
4127041	Rate Control Knob	12704			13
4142371	Tie Bar	14237			14
4142861	Spring Housing Assembly	14286			15
4127081	Pointer	12708			16
4150291	Handle Brace	15029-1			17
4150461	Upper Handle Assembly	15046			18
4140471	Handle Lever Assembly with chain	14047			19
4148701	Handle Grip (pair)	14870			20
4144151	Control Tube	14415-1			21
4144091	Control Tube Brace	14409			22
4150481	Hopper Handle	15048			23
4142421	Fastener Package	14242-3			24

*indicates parts included with hopper assembly