


# Parts Diagram - SS-2



## Parts List

ITEM	PART NO.	DESCRIPTION
1	14475-1	HOPPER ASSEMBLY
2	14479-1	SHUTOFF BAR ASSEMBLY
3	14228-1	AGITATOR/AXLE ASSEMBLY LH. & RH.
4	14231	BEARING SUPPORT ASSEMBLY
5	14235	AGITATOR BAFFLE
6	14227	END HANGER
7	14007	AXLE GREASE SEAL
8	14222-1	PLATE ASSEMBLY-BEARING END
9	90005	GREASE FITTING
10	14006	AXLE BEARING
11	15043	WHEEL & TIRE ASSEMBLY
12	12714	LEG
13	12704	RATE CONTROL KNOB
14	14237	TIE BAR
15	14286	SPRING HOUSING ASSEMBLY
16	12708	POINTER
17	15029-1	HANDLE BRACE
18	15046	UPPER HANDLE ASSEMBLY
19	14047	HANDLE LEVER ASSEMBLY W/ CHAIN
20	14870	HANDLE GRIP
21	14415-1	CONTROL TUBE
22	14409	CONTROL TUBE BRACE
23	15048	HOPPER HANDLE
24	14242-3	FASTENER PACKAGE

## Ordering Parts

See diagram for assistance in identifying specific parts. When ordering parts, be sure to include:

- 1) Spreader model number (AGC8008-1)
- 2) Spreader model name (SS-2)
- 3) Part number
- 4) Description of part (refer to list)



**For More Information Call...**

Agrium Advanced Technologies customer service at:

**1-800-461-6471**



Agrium Advanced Technologies  
10 Craig St  
Brantford ON N3C 1X2  
1-800-461-6471  
www.turfpro.ca